



Fulflo® SWC Filter Cartridges

- Polypropylene
- Cotton

Wound Depth Series

Economical Filtration Solutions With String Wound Depth Cartridges

Parker Process Filtration's SWC Filter cartridge offers a wide range of fibers and core materials. Roving is wound onto a center core for strength. The diagonal pattern of the media forms a tight, interlocking weave. Parker Process Filtration has one of the world's largest manufacturing plants for wound cartridges, offering superior quality along with technical, engineering and marketing support.

Nominal removal ratings from 1µm to 100µm are available.

Applications

- Animal Oils
- Concentrated Alkalies
- Dilute Acids & Alkalies
- Organic Acids & Solvents
- Mineral Acids
- Oxidizing Agents
- Petroleum Oils
- Potable Liquids
- Vegetable Oils
- Water
- Prefilter for R.O. Membranes



Features and Benefits

- SWC's provide excellent compatibility with a variety of organic solvents, animal, petroleum and vegetable oils.
- Optional core covers available to assure fiber migration control.
- Multiple length cartridges minimize change out time, eliminate spacers and are available to fit competitive filter vessels.
- Cotton and polypropylene materials are FDA listed as acceptable for potable and edible liquid contact according to CFR Title 21.
- Continuous strand roving geometry provides performance consistency
- Extended center core option eliminates the need for cartridge guides in competitive and Fulflo multicartridge vessels.
- One piece extended length center cores are available in tinned steel, 316 stainless steel and 304 stainless steel.
- A special snap-in extender is available for polypropylene cores.
- FDA grade polypropylene (DOE only) certified to ANSI/NSF61 standard for contact with drinking water components.

Process Filtration Division



PROSEP FILTER SYSTEMS LTD
Unit G19
River Bank Way
Lowfields Business Park
Elland
West Yorkshire
HX5 9DN

Tel: 01422 377367

Fax: 01422 377369

Email: enquiries@prosep.co.uk

www.prosep.co.uk

Map and Directions to Prosep Filters Limited



Leave M62 at Junction 24.

At roundabout adjacent to Cedar Court Hotel take 2nd exit onto dual carriageway (A629), signposted Halifax.

Take 1st exit slip road.

At roundabout at end of sliproad, take 3rd exit off.

This is the entrance to Lowfields Business Park.

Proceed straight over 1st roundabout.

At next roundabout take 2nd exit onto River Bank Way - Prosep Filters can be found on the left after the S-bend.

[Link to Google Maps](#)