



Fulflo® XTL™ Filter Cartridges

- Polypropylene
- Cotton

Wound Depth Series

Technologically Advanced Wound Cartridge Design Doubles Cartridge Life and Improves Performance

The unique construction of Parker's patented* Fulflo® XTL™ (extended life) cartridges provides twice the average life of conventionally wound cartridges for process fluid filtration. Computer modeling has optimized the wound cartridge geometry maximizing the use of the internal cartridge surface area. The enhanced design provides improved dirt-holding capacity (twice the average) over standard wound cartridges, while providing true controlled-depth filtration.

Fulflo XTL cartridges are available in nominal (90%) ratings of 1µm, 3µm, 5µm, 10µm, 20µm and 30µm.

Applications

- Potable Liquids
- Organic Solvents
- Process Water
- Photoprocessing
- Chemical Process
- Disposal Well
- Pharmaceuticals
- Lubricants
- Cooking Oils
- Amines
- R.O. Prefiltration



Features and Benefits

- XTL cartridges result in significant cost savings based on fewer system interruptions, decreased labor expenses for change outs, and reduced inventory and cartridge disposal costs.
- Unique computer programming capability permits the design and manufacture of special cartridge constructions to suit the requirements of nearly any filtration application.
- "M" polypropylene and "C" cotton materials are FDA listed as acceptable for potable and edible liquid contact according to CFR Title 21.
- XTL wound cartridges fit all Fulflo housings and most competitive housings without compromising final product clarity or flow characteristics of the cartridge. The most noticeable difference is the extended life savings offered by XTL cartridges.
- Extended center cores are available in tinned steel, 316 stainless steel and 304 stainless steel.
- A special snap-in extender is available for polypropylene cores.

Process Filtration Division

PROSEP FILTER SYSTEMS LTD
Unit G19
River Bank Way
Lowfields Business Park
Elland
West Yorkshire
HX5 9DN

Tel: 01422 377367

Fax: 01422 377369

Email: enquiries@prosep.co.uk

www.prosep.co.uk

Map and Directions to Prosep Filters Limited



Leave M62 at Junction 24.

At roundabout adjacent to Cedar Court Hotel take 2nd exit onto dual carriageway (A629), signposted Halifax.

Take 1st exit slip road.

At roundabout at end of sliproad, take 3rd exit off.

This is the entrance to Lowfields Business Park.

Proceed straight over 1st roundabout.

At next roundabout take 2nd exit onto River Bank Way - Prosep Filters can be found on the left after the S-bend.

[Link to Google Maps](#)