PROPLEAT PP Food and Beverage

Filter Cartridges





PROPLEAT PP filters have been developed to bridge the gap between meltblown depth filters and absolute rated pleated media filters for liquid clarification.

Their continuous length and all polypropylene construction results in a robust yet economical design that maximizes the effective filtration area and provides wide chemical compatibility, coupled with low extractable levels.

All PROPLEAT PP cartridges exhibit 99% efficiency at their given retention rating, providing consistent and economical clarification in a diverse range of applications.


Features

- A wide range of retention ratings
- I Continuous length thermally bonded polypropylene sleeve and core
- Elevated temperature option available for hot water sanitization and steam sterilization


Performance Characteristics

Benefits

- Flexibility to excel in a wide range of clarification applicaitons
- Strong, robust construction to provide stable retention in diverse process conditions
- Ability to be cleaned and sterilized in-situ



Filtration Stage



PROPLEAT PP Food and Beverage

Specifications

Materials of Construction

Filtration Media:	Polypropylene		
Upstream Support:	Polypropylene		
Downstream Support:	Polypropylene		
Inner Support Core:	Polypropylene		
Outer Protection Cage:	Polypropylene		

- End Caps: Polypropylene
- End Cap Insert (if applicable): 316L Stainless Steel*
- * Not available in B and L End Cap variants
- Standard o-rings / Gaskets: Silicone / EPDM

Food Contact Compliance



Materials conform to the relevant requirements of FDA 21 CFR Part 177, current EC1935 / 2004 and current USP Plastics Class VI - 121 °C.

Recommended Operating Conditions

Up to 70 °C (158 °F) continuous operating temperature and higher short-term temperatures during CIP to the following limits:

Temperature		Max Forward dP	
°C	°F	(bar)	(psi)
20	68	5.0	72.5
40	104	4.0	58.0
60	140	3.0	43.5
80	176	2.0	29.0
90	194	1.0	14.5
>100 (steam)	>212 (steam)	0.3	4.0

Effective Filtration Area (EFA)

10" (250 mm) Up to 0.6 m² (6.5 ft²)

Cleaning and Sterilization

PROPLEAT PP cartridges can be repeatedly steam sterilized in-situ or autoclaved at up to 121 °C (250 °F). They can be sanitized with hot water at up to 90 °C (194 °F) and are compatible with a wide range of chemicals.

Retention Characteristics

The retention characteristics of PROPLEAT PP filter cartridges have been determined by a single-pass technique using suspensions of ISO 12103 Pt. 1 A2 Fine and A4 Course test dust in water.

99% approximate ratings at lower efficiencies				
Media	99%	95%	90%	
Code ß Ratio	100	25	10	
E	0.8	0.7	0.6	
G	1.0	0.9	0.7	
Н	3.5	2.3	1.0	
K	4.8	3.8	2.8	
L	7.2	6.0	4.5	
М	10.0	8.0	6.0	
Ν	12.0	9.0	7.0	
Ρ	18.0	13.0	10.0	
U	40.0	30.0	25.0	

Recommended Rinse Volume

Prior to use - 10 litres per 10" (250 mm) cartridge.


Minimum Box Quantities All cartridges supplied in boxes of 6.

Dimensions

Standard Lengths (DOE seal to seal)

Length	B Style	L Style
1	9 ⁷ / ₈ " (250 mm)	9 ⁷ / ₈ " (250 mm)
2	19 ¹ / ₂ " (498 mm)	20 (508 mm)
3	29 ³/ ₈ " (746 mm)	30 ¹ / ₈ " (766 mm)
4	39 ¹ / ₈ " (994 mm)	40" (1014 mm)

Ordering information





Parker domnick hunter has a continuous policy of product development and although the Company reserves the right to change specifications, it attempts to keep customers informed of any alterations. This publication is for general information only and customers are requested to contact cur Process Filtration Sales. Department for detailed information and advice on a products suitability for specific applications. All products are sold subject to the company's standard conditions of sale.



enquiries@prosep.co.uk

WE ARE YOUR '**ONE STOP SHOP**' FOR ALL OF YOUR FILTRATION REQUIREMENTS

LIQUID FILTRATION

- CARTRIDGES
- FILTER BAGS
- VESSELS
- STRAINERS

AIR FILTRATION

- VENT FILTERS
- STERILE AIR
- VACCUM
- AIR-CONDITIONING
- FILTER MEDIA

DOMESTIC

- ULTRAVIOLET
- TREATMENT OF BOREHOLES,
- SPRINGS & WELLS
- WATER TESTING

FUEL FILTRATION

DIESEL, AVIATION



Prosep Filter Systems Ltd Unit G19, River Bank Way, Lowfields Business Park, Elland, West Yorkshire HX5 9DN Phone: 01422 377367 email: sales@prosep.co.uk www.prosep.co.uk



for all your filter requirements

PROSEP

FILTER SYSTEMS LTD